

# Tablet Displays (iPad Stand™)

## Applicable Products:

IPDTF (TableTop Flange)

1. Align base over table and mark hole locations. Using a 9/32 drill bit, drill clearance holes into table (fig. A-1).
2. Sandwich table in between flange bases and secure stand to table using provided Phillips head screws (fig. A-2).
3. Remove acrylic cover using small tamper-proof key provided. Place tablet inside and reassemble unit (fig. B). If ball joint loosens on back, use the large tamper-proof key to retighten it securely.

