

Lock & Roll Setup



2
Slowly raise the graphic and attach it to the groove located on the rear of the top rail.



3
The support pole can be adjusted according to the height of the graphic. To avoid damage, ensure the pole isn't overextended.



1
Insert the support pole into the pole cup. Twist the pole sections to where they're loosened and can move freely.



4
Twist the pole sections to tighten them to where the pole remains extended to the desired height.

To take down the display:



1
Twist the pole sections to loosen them.



2
Lower the support pole with it still attached to the top rail to begin retracting the graphic back into the base.



3
Once the support pole is fully lowered, unhook the top rail from the pole clip. Then, guide the graphic the rest of the way into the base. Remove the support pole.