




# X Flex Setup Instructions




1. Remove the X Flex stand and rolled banner from the travel bag.




2. Unfold the adjustable arms that are attached by bungee cords and insert them into the sockets in the main hub.




3. Loosen the adjustment knob for the rear support leg and adjust the leg to an appropriate angle, then tighten the knob.




4. Twist the lower section of the rear support leg clockwise to loosen the telescopic section. Extend it to the desired length and twist counter-clockwise to tighten.




5. Set the stand up so it is balanced on two lower banner arms and the adjustable rear leg.




6. Attach the banner loosely to the stand by putting the grommets in the corners of the banner over the hooks at the ends of the banner support arms.



7. Loosen the thumb screws that secure the adjustable arms, and extend the arms until the banner is under tension, then tighten the thumb screws.



8. The poles should be flexed when the arms are properly extended, so that the banner is under tension and kept smooth.



9. If the banner is not under even tension, adjust the length of the corresponding arm from the back to compensate until the banner is flat and even.